

SDS1000X-E Firmware Update Instructions

1. Put the file (.ads) to U-disk.
2. Insert the U-disk.
3. Press the “Utility” button -- Page 3/3 – Update -- Firmware
-- Select the firmware (.ads) -- Press To Update --
Waiting for about 1 minute -- Firmware decompressed! Please
restart scope and wait.
4. Restart the scope.
5. Check the software version (Utility -- Page 1/3 -- System status).