
How to quickly save a picture with SIGLENT SDS Oscilloscopes

October 25, 2017

Many SIGLENT scopes feature a quick print key located on the front panel.

To save a copy of the display image as a bitmap file (BMP):


1. Verify that the Print key is assigned to the save to USB. This is indicted by an “S” located at the top of the display:



If the scope indicates “P”, then you will need to reconfigure the print button.

2. Insert a USB memory device into the USB port located on the front panel of the scope

3. Press the Print button located on the front panel:




Configuring The Print Button


1. Press Utility

2. Press “Next Page” until you get to page 2/4


3. Select Print Setup



4. Set Print Key to “Save Picture”



5. Press Menu Off to get back to the main display



North American Headquarters

SIGLENT Technologies NA
6557 Cochran Rd Solon, Ohio 44139
Tel: 440-398-5800
Toll Free:877-515-5551
Fax: 440-399-1211
info@siglent.com
www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH
Staetzlinger Str. 70
86165 Augsburg, Germany
Tel: +49(0)-821-666 0 111 0
Fax: +49(0)-821-666 0 111 22
info-eu@siglent.com
www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel:+ 86 755 3661 5186
Fax:+ 86 755 3359 1582
sales@siglent.com
www.siglent.com/ens