

Using EasyScopeX Software to retrieve Average Waveform Data

October 24, 2017

Waveform averaging can be a useful method to decrease noise in a particular signal. The SIGLENT SDS series of oscilloscopes can easily collect average waveform data using EasyScopeX Software.

NOTE: At this time, average waveform data is not able to be saved in CSV format via the front panel USB connection to a USB memory stick.

Initial Setup

- Download NI-VISA Runtime Engine that matches your operating system, if your computer does not already have the VISA library.

It can be downloaded from National Instruments: <http://bit.ly/2pw5gQW>

- VISA library installed. This is the communication library used by EasyScope X software to communicate with the instrumentation


- Download EasySpectrum Software from the SSA3000X Product Page on the SIGLENT America website: <http://bit.ly/2okc8wG>

Connect and Collect


1. Connect the scope to the computer using a USB or LAN connection and power it on.

NOTE: This example uses a USB connection for communication between the scope and computer.

2. Open an instance of EasyScopeX by clicking on the desktop icon:



3. Add Device and select the session address for the instrument you wish to connect:




4. Configure the instrument to capture the signal of interest. You can perform this manually on the front panel, or you can use the Virtual Panel control.

Select Virtual Panel > Acquire > and press the button labeled Acquisition until the type = Average:



5. Select Waveform, and use the Play/Pause button to acquire the waveform of interest. Then, select Save > select the channel of interest > select the type of CSV to save > Press Save to open a file dialog box.





North American Headquarters

SIGLENT Technologies NA
6557 Cochran Rd Solon, Ohio 44139
Tel: 440-398-5800
Toll Free: 877-515-5551
Fax: 440-399-1211
info@siglent.com
www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES GERMANY GmbH
Staetzlinger Str. 70
86165 Augsburg, Germany
Tel: +49(0)-821-666 0 111 0
Fax: +49(0)-821-666 0 111 22
info-eu@siglent.com
www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.
Blog No.4 & No.5, Antongda Industrial Zone,
3rd Liuxian Road, Bao'an District,
Shenzhen, 518101, China.
Tel: + 86 755 3661 5186
Fax: + 86 755 3359 1582
sales@siglent.com
www.siglent.com/ens